

iControl Vacupad

VACUUM SEAT CUSHION FOR USE IN AUTOMOTIVE RACING SEATS.



iControl[®]



The iControl Vacupad enables quick and easy adjustment of a racing seat to the individual body shape.

Optimize your seat in a way that is usually reserved for professional drivers, and do so anew before every trip.

The iControl Vacupad increases support in the seat, distributes pressure evenly over a larger contact area and improves comfort.

HOW TO USE:

1. Remove the original seat cushion from the seat if possible.
2. Place the cushion in the racing seat.
3. Make sure that the filling is distributed as evenly as possible over the entire volume of the cushion.
4. Sit down in the racing seat on the cushion.
5. Use the included pump to vacuum the cushion through the valve until it is hard.
6. After use, release the vacuum by pressing the valve from the side.



CAR ERGONOMICS

SCOPE OF DELIVERY:

- 1 Vacupad seat cushion
- 1 Vacuum hand pump

The iControl Vacupad complies with Federal Motor Vehicle Safety Standard No. 302
Flammability of interior materials. Keep away from pointed or sharp objects
to avoid damage.

Developed by:
iControl automotive GmbH
Postweg 4, 82024 Taufkirchen, Made in Taiwan

Distributed by:
TRACK & STREET - Literide e.K.
Unterfeldring 27, 85256 Vierkirchen,
Phone: +49 (0)89 318 67 341
Mobile: +49 162 2723 390
Web: www.trackandstreet.de
E-Mail: service@trackandstreet.de